

Manual installation

Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If this shower head is installed at low pressure (tank fed) then the minimum height from the outlet to the underside of the cold tank should be 1.8 metres to ensure adequate performance.

This shower head should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

Cleaning/General Care

Chrome and Gold plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

Fixed Shower Arm & Head

Installation Guide

Follow these instructions before fitting the shower arm and head.

Prior to installation, please check that your plumbing system is adequate and that all pipes have been sufficiently flushed through.

1. Turn off the mains cold water supply. The mains stopcock is usually found where the supply enters the building.
2. It is also recommend that any hot water heating systems are turned off.
3. Drain the hot and cold water systems. To ensure complete drainage, open all taps.
4. Turn supply water line off and flush to remove debris.
5. Remove back fixing nut from the threaded part of the arm.
6. Insert the threaded part of the arm through the access point in the wall or ceiling and ensure it is anchored to a suitable solid structure.
7. Use PTFE tape when making pipe connections in this installation.
8. Tighten the back fixing nut against the back of the wall or ceiling.

9. Tighten the washer to make a tight connection.
10. Connect your pipework to the arm using a **½" BSP tap connector (not supplied)**
11. Slide the concealing flange up to the wall or ceiling surface and secure.
12. Apply PTFE tape to the thread at the shower head end of the arm.
13. Screw the head onto the arm.
14. Turn supply water back on and check for leaks prior to finishing the wall surface.

