

Freestanding Bath Shower Mixer

Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If this tap is installed at low pressure (tank fed) then the minimum height from the outlet of the nozzle to the underside of the cold tank should be 1.8 metres to ensure adequate performance.

This tap should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

Cleaning/General Care

Chrome and Gold plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

Customer Care Helpline

Telephone: 01386 800750


Email: customerservices@plumbworld.co.uk

Installation Guide

Follow these instructions before fitting the tap.

Prior to installation, please check that your plumbing system is adequate and that all pipes have been sufficiently flushed through.

1. Turn off the mains cold water supply. The mains stopcock is usually found where the supply enters the building.
2. It is also recommend that any hot water heating systems are turned off.
3. Drain the hot and cold water systems. To ensure complete drainage, open all taps.



4. Drill a hole min 57mm diameter-max 65mm diameter in the floor.
5. Place the flange over the standpipe and then connect it to the base.
6. Put flexible hoses up through the standpipe and then attach the flexible hoses to the mixer.

Please note not to reverse the cold and hot supply.

7. Locate the assembly in the desired position with the flexible hoses through the prepared hole, whilst holding the flange, secure the standpipe.

NOTE: If mounting into wooden floor, secure the standpipe using screws only (wall plugs are not needed). If mounting into solid floor, drill suitable sized holes for wall plugs first, then insert wall plugs in the floor and finally secure the standpipe using screws. Where required ensure correct plugs for your floor type are used.

8. Connect the flexible hoses to water supplies.
9. Having first checked all new connections, turn on the mains stop cock, close all taps except the new mixer and as system starts to refill, check for leaks.
10. Once you have satisfied yourself that there are no leaks, switch on the water supply.

Hand Shower Installation

Insert a washer into each end of the shower hose and then screw it to the hand shower and mixer.

Operation

Pull out diverter to operate the shower. It can be locked by turning at an angle.